The engine air filter is located on the left side of the motorcycle, and behind the air filter cover. The engine air filter should be inspected every 5000 miles (8000 km) and more often when riding in dusty conditions.

Removal

1. Remove two fasteners holding air cleaner cover and insert to backing plate
2. Remove insert, cover and gasket
3. Remove air cleaner element.

Cleaning Procedure:

1. Spray K&N Air Filter Cleaner onto both sides of the air filter until it completely saturates the pleated material.

A. Apply K&N Air Filter Cleaner to clean side of filter
B. Apply K&N Air Filter Cleaner to dirty side of filter

Allow cleaner to soak into both sides of air filter for 10 minutes to loosen the dirt. Do not let cleaner dry on air filter.

2. Rinse:

Rinse off air filter with cool low-pressure water. Allow gravity to flush dirt out of air filter by applying water to the clean side of the filter; up and down the length of the pleats.

Continue to rinse the filter until all traces of cleaner are gone. If the filter is extremely dirty it may be necessary to repeat steps 1 and 2. If there are spots of dirt remaining on the filter, spray each spot directly with cleaner, allow a few minutes for it to soak and repeat rinsing step.

3. DRY

After rinsing, gently shake off excess water and allow filter to dry naturally. Do not proceed to the oiling step until the filter is completely dry.

Install

1. Install air filter element
2. Insert gasket into backing plate groove
3. Install air cleaner cover and insert
4. Install fastener and torque to 9-11 FT LBS